




QUICK PROGRAMMING GUIDE FOR MAESTRIA™ 50 RTS MOTORS

PROGRAMMING MODE

MANUAL ADJUSTMENT OF THE UPPER END LIMIT AND THE LOWER END LIMIT

1) Position the screen at the desired UPPER Limit

2) Press MY and DOWN simultaneously:
the screen lowers.



3) Position the screen at the desired
LOWER Limit.

4) Press MY and UP simultaneously:
the screen raises.



5) Press MY until the screen jogs to
validate the end limit setting.

